

# T-6/SNJ Standard Traffic Pattern

Copyright ©1999 Warbird Adventures, Inc. (407) 870-7366

Enter traffic pattern  
on a 45° to the  
down wind leg.  
(<150 MPH)  
At Traffic Pattern  
Altitude  
(800-1000 Feet)



At 500 ft.  
28"/1900 RPM

At Traffic Pattern  
Altitude (800-1000 ft.)  
Cruise at  
26"/1800 RPM

Climb at 100 MPH

**Pre-Landing Check list:**

Gear	Down
Flaps	As needed
Trims	<u>Both</u> 9 o'clock
Prop	Full Forward
Mixture	Full Rich

**At all times  
when able:  
Stay within  
Gliding distance!**

(Slowly reduce power on down wind)

Rotate at 85 MPH  
Gear up at 100 Feet  
Climb power:  
30"/2000 RPM

Take Off power  
36"/2250 RPM  
Engine instruments  
Must be in the Green

20"/1800 RPM  
Abeam touch down  
Gear down (<150 MPH)

20"

Verify down &  
locked

At 180° point  
500-600 Feet  
Flaps down  
Trims at 9 o'clock

Over numbers  
Gear down  
15"/1800 RPM

Approach at 90 MPH

15"/1800 RPM

Verify down &  
locked

Power Off  
Prop Forward  
Mixture rich  
90 MPH

Power Off  
Prop Forward  
Mixture rich

**Black – Normal Pattern**  
**Blue – Overhead approach**

At 90° point  
Flaps down (<125 MPH)  
Trims at 9 o'clock

360° Overhead approach  
800-1000 Feet  
120 MPH  
20"/1800 RPM