

Inflatable Bounce House Instructions...

How to Set-up

- 1) Check ground for a flat level surface void of any rocks, sticks, pine cones, etc. (anything that may puncture the bottom of the Inflatable). Also check height clearance for trees, power lines, or overhead obstructions. Tarps should be placed underneath all Inflatables before proceeding to Step 2. (Never operate the Inflatable on a hard surface without a tarp underneath).
- 2) Unroll the Inflatable in the direction you wish the Inflatable to face. Unfold until the Inflatable is completely flat and ready for inflation.
- 3) Attach the Blower(s) to the "Port" (extended air hose / blower tube). The "Port" is generally located in the very back or on the sides of the Inflatable. Tie off any additional "Ports" by turning the material clockwise and tying the tie around the Port. Leave a little air escaping so the Inflatable will not burst.
- 4) Close All Velcro / Zipper compartments.
- 5) Attach heavy extension cord(s) from power source. (Designate One - 20 amp fuse for each Blower. Generally, this equates to one - 110-volt Outlet for each Blower.) Use the extension cord(s) in the trailer and do not extend more than 100 feet from the power source.
- 6) Turn the Power on. (Blowers have an On/Off switch located on the blower.) While the Inflatable inflates- Check to make sure only slight air is escaping the vents or ports.
- 7) Check to make sure the Port (air hose) leading to the Blower is not twisted.
- 8) Secure the Inflatable by staking the unit on all 4 corners. Drive stakes half way in at a 45 degree angle away from the inflatable.

Safety Instructions / Operation

- 1) Adult supervision is required at all times. Never leave the Inflatable unattended or unwatched. Only jump and play on a fully inflated unit. DO NOT allow riders to play or climb on inside or outside walls or roof of unit, and NEVER allow riders to hang on or pull netting or columns.
- 2) Most Inflatables only allow 4-5 Guests on the Inflatable at a time. (Check Inflatable Instructions)
- 3) Guests must remove shoes, pocket items, glasses, jewelry, etc.
- 4) Diving and flipping are strictly prohibited. No back flips, roughhousing, horseplay or bouncing against walls. Guests should not take unnecessary risks.
- 5) No food, drink, or gum on or in the inflatable. NEVER spray the Bounce House with a water hose – Electricity and water DO NOT MIX!

*The Inflatable should not be operated/shut down if winds exceed 20 mph.

*The Inflatable should not be used in rain or lightning conditions.

How to Takedown

- 1) Check for any loose items left on the Inflatable. (Sweep or vacuum where appropriate).
- 2) All Guests should be clear of Inflatable- Including: stakes, flagging, weight bags, etc.
- 3) Turn Off or Unplug Blower. Disconnect the Blower from the Inflatable.
- 4) Open All Velcro / Zipper Flaps, Vents, and Ports to allow air to escape and the Inflatable to deflate. Deflation time varies on the Inflatable (10 – 20 minutes).

How to Roll an Inflatable

The Key to a Good Roll is to fold the material neatly in toward the middle of the Inflatable.

NOTE VISUAL STEPS BELOW FOR CORRECT METHOD

Visual Steps for How to Roll an Inflatable:



Step 1: Fold all material toward the middle of the Inflatable and expose the bottom/edge seams of the Inflatable.



Steps 2-3: Fold one side of the Inflatable, lengthwise, $\frac{1}{4}$ distance to the other side. Repeat on other side (edge seams should meet in the middle).



Step 4: After folding the Inflatable twice lengthwise, walk out air towards Ports (Blower tubes).



Step 5: Fold the Inflatable in half lengthwise and walk out air towards Blower tubes again. Tuck in any extra material.



Step 6: Push straps 2-3 feet under the Inflatable (at Blower tube end) before rolling. Doing so now will keep you from lifting the entire roll later. (Ours have D-ring buckles, not "S" hooks).



Step 7: Begin rolling from opposite the Blower tube end. (This pushes air out as you roll.) Take your time and roll as tightly as possible. Keep the roll lined up, tuck in any extra material, as you go and do not allow any part of the roll to sag. Loose rolls are difficult to move.



Step 8: Tuck in Ports/Blower tubes and tie off with the straps. Tuck in hoses or extra material. Tighten the straps tight. Be careful not to break the straps.



Step 9: Stand up Inflatable for moving to the trailer (Use 2 wheeler)
(Ours do not have storage bags)