






## How to Measure Hand Rail Diameter

Hand Rail Series parts are available to fit a variety of rail diameters. In order to properly determine which diameter is correct for your application, you can measure your rail diameter in a few simple steps:

<b>Step 1:</b> Align a piece of paper along the outside of the rail.	<b>Step 2:</b> Wrap the paper around the rail.	<b>Step 3:</b> Draw a line where the paper meets.
		
<b>Step 4:</b> Lay the paper flat and measure the distance from the edge of the paper to your line.	<b>Step 5:</b> Calculate the pipe diameter by dividing your measurement by 3.14.	<b>Step 6:</b> This is the number used to order your handrail part.
		For example, if your pipe measurement was 4.7", dividing that by 3.14 gives you 1.5" and this is the number you use for your order.

Instead of paper, you can also wrap a string around your hand rail, mark the point at which the string overlaps and measure the length of the string.